

AESTHETIC CEMENTATION CHECKLIST

01	REMOVAL OF PROVISIONALS Anesthetize patient Place Optragate Remove micro-leakage if any
02	RESTORATION SEAT VERIFICATION AND TRY-IN Check fit of restorations one at a time, verify marginal integrity Check fit of restorations 2 by 2, then all together (verify fit of proximal contacts) Use try-in paste to verify shading
03	RESTORATION PREPARATION (ALL E.MAX, LISI, EMPRESS RESTORATIONS ARE ETCHED PRIOR TO DELIVERY) Ivoclean each preparation Fill with cement of selected shade Place Restorations in light secure box
04	TEETH PREPARATION Bonding steps Etch all teeth (3 at a time) Apply Desensitizer, blot dry Apply Primer - let air dry thoroughly Cure 10 seconds per tooth
05	CEMENTATION Seat Restorations starting with centrals, then laterals, cuspids, and so on Tack and wave, remove excess Separate contacts with serrated saw and/or floss contacts with floss
06	FINAL POLYMERIZATION Coat margins with De-Ox or glycerin Light cure all restorations for 40 seconds facial/20 seconds lingual per tooth Remove any cords and floss teeth
07	FINISHING Use Finishing strips (3M 1954N then Epitek: Blue-Green-White-Coral) Clean up cement with scalpel, finish margins with high speed 15 micron diamonds, followed by 30 fluted carbides Adjust Occlusion (special finishing kits for Zirconia) Polish with ceramic polishing kit and Diashine on robinson brush if needed Take final photo





